
# **INSTRUCTION MANUAL**

## Setup and use your digital video baby monitor


### **Installing Baby Unit**

A. Place Baby Unit on a flat surface, such as a desk or shelf or mount the camera on a wall.



Never place the baby unit or the cord within 1 meter of the crib.

**B.** Connect the small plug of the power adapter to the Baby Unit and the other end to a suitable electrical outlet. Only use the enclosed adapter (5V DC 1000mA). Slide the switch to "ON" position to turn on baby unit. Green power LED is turned on.



#### C. Connecting the power supply for the Parent Unit.

Connect the small plug of the power adapter to the parent unit and the other end to a electrical outlet. Only use the enclosed adapter (5V DC/1000mA). Recommend charging time of at least 3 hours before first use.






### Precaution: use of battery for Parent Unit

Only charge the battery when the battery life indicator is low. Constant recharging of your battery before the low battery indicator light comes on will decrease the life of your batteries.

When battery is low, the power on off LED (icon) will flash red and on screen display battery icon will flash red indicating that the battery needs to be charged.



# **WARNING** AC Adapters provided.

**STRANGULATION HAZARD** — Children have STRANGLED in cords


## WARNING


**Warnina Information** 

\* For adult use only

## Function of keys and LED indicators

#### Parent Unit





Unit on a stable, level surface.

(1)	On/Off	Press and hold to switch "On/Off" the unit.
<b>(</b> )	Volume up/down	Press to increase and decrease volume.
SELECT/MENU	Menu	Press to open and select menu options.

# **Baby Unit** Antenna Camera Antenna Press and hold to turn on baby unit. Power Short press to turn off baby unit.

When camera is switched on, press and hold till power LED

## Start to use monitor

#### Status bar

Signal strength reference

Monitor is muted

Battery level


VOX - OFF Switch off power saving mode.

VOX - LOUD Power saving mode is switched on. Loud noise to activate screen.

VOX - MEDIUM Power saving mode is switched on. Medium noise to activate screen.

VOX - QUIET Power saving mode is switched on. Little noise to activate screen.

Power saving mode is switched on. Camera set up sound trigger level automatically according to camera surrounding environment. Any louder sound will activate monitor.



#### Menu operation

#### Power saving mode

To activate Parent unit from Power saving mode.

Power saving mode off.

Power saving mode is switched on. Loud nose to activate screen.

Power saving mode is switched on. Medium nose to

Power saving mode is switched on. Little nose to activate screen.

Power saving mode is switched on. Camera set up sound trigger level automatically according to camera surrounding environment. Any louder sound will

Audio keeps on or shut off when monitor is set to power

Audio keeps on when monitor is set to power saving

Audio is shut off when monitor is set to power saving mode.



Use only when camera is lost link with monitor.

## WARNING THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULT SUPERVISION

- strongly recommended to have an adult directly checking on your baby. Premature babies or children

## **Battery Warning**

- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire

PAIR

Pairing button

 $\cdot$  Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the

removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example energy and, if not installed and used in accordance with the

## **FCC Radiation Exposure Statement**

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other  $\frac{1}{2}$ 

This device complies with Industry Canada licence-exempt RSS standard.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en c

## LBTech's baby monitor warranty policy

LBTech will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the unit is defective in workmanship or materials. To claim your repair/replacement, the product must be returned to LBTech together with a copy of the purchase receipt. In the absence of the purchase receipt, the warranty